⚠ **WARNING:**
CHOKING HAZARD - Small parts. Not for children under 3 years.

INSTRUCTIONS

REMOTE CONTROL 12 LED FLOATING LANTERN

Button

FEATURES

* Floating / Waterproof
* 12 White LED Bulbs
* Remote Control Allows Easy ON/OFF Use
* Remote Transmitter Uses A 3V Lithium Battery Included
* Operated By 4 "D" Size Batteries (Not Included)

OPERATION

The Lantern Can Be Turned ON Or OFF By Manual Or Remote Control

Manual Usage
- Turn Switch To " ☼ " ON

Manual   Remote   OFF

Remote Control Usage
- Turn Switch To " ▽ " ON
- Use The Remote Control Transmitter To Turn ON/OFF
- Remote Can Be Used 35 Feet From The Lantern

WARNING !!

-This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

-Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.
-This device transmits a radio frequency signal. The radio frequency signal should not be modified.

Item No. 51296

BATTERY REPLACEMENT

- The Lantern Is Powered By 4 "D" Size Batteries (Not Included)
- Turn Lantern Upside Down And Turn Base Cover Counter-Clockwise And Lift Off.
- Remove Battery Holder From The Body And Insert 4 New "D" Size Batteries (Not Included) According To The Mark On Battery Holder.
- Reassemble The Battery Holder And Base Cover.

CLOSE   OPEN

IMPORTANT :

- DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES.

The Remote Controller Is Powered By A "CR-2032" 3V Lithium Button Size Battery.
- Turn The Remote Controller Back And Pull The Battery Holder Out.
- Replace The Battery With A New "CR-2032" 3V Lithium Button Size Battery.
- Make Sure The Battery Installed In Right Position According To Make On The Body.
- Reassemble The Battery Holder By Insert Into Remote Controller Body.

Pull the battery holder out.
Push the battery holder in
FIG. 3

Distributed by :
Cabela's Inc.
Made in China